



Base Replacement

This guide will give you a clear walk through on base disassembly.

Written By: Han Shih



INTRODUCTION

Prerequisite Only



TOOLS:

- [Spudger](#) (1)
 - [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Base




- Turn the base over. You will see four 11mm Phillips #0 screws, one in each corner.
- Use a screwdriver to remove all four 11mm Phillips #0 screws.

Step 2



- Locate an easy seam for entry and insert the metal spudger to separate the plastic. Use the spudger in multiple places if necessary.

 Opening the base may require exerting significant force as it is bound together tightly. This step can be dangerous.

 The spudger is designed to make this step easier.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-16 05:42:32 PM.