



Bosch 3727DEVS Microfilter Dust Canister Replacement

Replacing the Microfilter Dust Canister with a new one.

Written By: Daniel Spruill



INTRODUCTION

Purchase a new Microfilter Dust Canister.



PARTS:

- [Microfilter Dust Canister](#) (1)
-

Step 1 — Microfilter Dust Canister



- Move the support slider located on the bottom of the handle towards the sander.

Step 2



- Press the pinch point tabs located on each side of the dust canister and slide the dust canister away from the sander.

Step 3



- Take the locking tab from the original dust canister and place it on the new one. To do this, slide it downward onto the new dust canister until it snaps into place.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 10:32:46 PM.