



# Removing Delphi MyFi XM2GO Battery

This guide demonstrates removing the user-removable Lithium Ion battery.

Written By: Scott Byer





## Step 1 — Removing Delphi MyFi XM2GO Battery Cover



- Flip the Delphi MyFi XM2GO Device on its back to start the cover-removal process.
- The back cover is the access point for the user-removable battery. Removing the back cover also gives the user access to the hard-reset button.

## Step 2



- Locate the large button on the top back of the device. This button is used to release the latch holding the sliding back cover in place.
- Press this button at the top while making a firm grip on the battery cover.
- As the button is pressed, move the cover towards the bottom of the device while applying moderate pressure to the cover.
- Be careful to not press down too hard on the battery cover as it is made of plastic.
- The battery removal tab may pop up during the cover removal process.

### Step 3



- After the cover is removed, the white Lithium Ion battery is visible.

### Step 4 — Removing Delphi MyFi XM2GO Battery



- Removing the back cover allows access to the user-removable battery.
- Should the battery need to be replaced or swapped, following these steps will aid in the process.
- The battery comes from the manufacturer with a pull tab with a web address printed on it to direct the user in purchasing a new battery.
- Holding the device, grab the tab with thumb and index figure.



## Step 5



- Pull down on the tab so that the battery block moves a few millimeters towards the bottom of the device.
- The battery will move parallel to the back of the device while a latch at the top is freed with the downward motion.
- There is a pivot point at the bottom of the battery where the contacts connect to the battery.
- After the latch at the top is disengaged, pivot the battery away from the back and the battery will be free.

## Step 6



- With the battery removed, the back of the device reveals more information about the product.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-05 07:54:49 AM.