



Shop-Vac MC150A Filter Cage Replacement

Use this guide to replace the filter housing in the Shop-Vac.

Written By: Ngunlian



INTRODUCTION

This guide will walk you through the process of replacing the filter house in a Shop-Vac MC150A.



TOOLS:

- [Allen Wrench](#) (1)
- [2.5 mm Hex Bit](#) (1)



PARTS:

- [Visit \[www.shopvacstore.com\]\(http://www.shopvacstore.com\) and buy replacement.](http://www.shopvacstore.com) (1)
-

Step 1 — Filter Cage



- Separate the power unit assembly (the black top) from the tank assembly (the red bottom).
- To open, grab the black clips on the side and pull out to un-hook from the red bottom.

Step 2



- Remove foam sleeve from filter cage

Step 3



- Unscrew the 2 H3.5 Allen screws attached to the filter cage.

Step 4



- Take out the filter cage, leave the black float, and replace the filter cage.

To reassemble your device, follow these instructions in reverse order.